ONERENT · QUICK USER GUIDE

# Pressure washer Kärcher HD 5/17 CX Plus

A short guide to the cold-water pressure washer: connecting, working and safe use.



## 1. Before you start

- Check that the kit contains everything listed in the hand-over record.
- The machine needs a water supply from a tap and a 230 V socket.

## 2. Connecting

- Connect the water supply hose to the tap and to the machine inlet; open the tap fully.
- Connect the high-pressure hose, the gun and the spray lance with the nozzle you need.
- Plug the machine into a 230 V socket (use no longer extension than necessary, fully unwound).

## 3. Working

- Before switching on, pull the gun trigger to let the air out until water flows evenly.
- Switch on and start washing from 30–50 cm; keep the jet further away from sensitive surfaces.
- After work, switch off, close the tap and pull the trigger to release the pressure.

## 4. Tips

- Use the flat jet for large areas and the rotary nozzle for heavy dirt, but not on wood or painted surfaces.
- Use only detergents made for pressure washers.

## 5. Safety and care

- Never point the jet at people, animals, electrical devices, tyres or the machine itself.
- Wear safety glasses and non-slip shoes.
- Do not lock the trigger and do not leave the machine running unattended.
- If the equipment does not work properly, stop using it and call us: +371 26537465.

## 6. Returning

- Return the equipment to Slokas iela 52N clean and complete — with all accessories listed in the hand-over record.
- Return the machine with the hose wound up and emptied of water.

Based on the Kärcher manufacturer’s instructions. Full manufacturer manual: www.kaercher.com.