ONERENT · QUICK USER GUIDE

Air blower Master 5000

A short guide to the air mover: placing it, choosing the speed and using it safely when drying floors and carpets.



1. Before you start

- Check that the kit contains everything listed in the hand-over record.
- Place the air mover on a flat, stable surface; the air inlet must be free.
- Make sure the cable and socket are dry; use an earthed 230 V socket.

2. Use

- Direct the air flow along the surface to dry — e.g. along a carpet or towards a wall.
- Switch on and choose one of the three speeds.
- In large rooms, place the air mover so that air circulates around the room; ventilate if needed.

3. Tips

- Drying is faster if the room is warm and the moist air is removed (ventilation or a dehumidifier).
- A washed carpet takes several hours to dry — check that it is completely dry.

4. Safety and care

- Do not cover the air inlet or outlet and do not put fingers into the grille.
- Do not point it at people for a long time; switch off and unplug before moving it.
- Do not use the machine if the cable is damaged.
- If the equipment does not work properly, stop using it and call us: +371 26537465.

5. Returning

- Return the equipment to Slokas iela 52N clean and complete — with all accessories listed in the hand-over record.

Based on the Master manufacturer’s instructions. The full manual is included with the device.