ONERENT · QUICK USER GUIDE

Wall scanner Bosch D-tect 150

A short guide to the wall scanner: choosing the mode, scanning and marking objects found.



1. Before you start

- Check that the kit contains everything listed in the hand-over record.
- Check the charge of the 4 AA batteries (or battery pack).
- Make sure the underside of the scanner is clean and dry.

2. Scanning

- Switch on and choose the mode for the wall — concrete, drywall, masonry, etc.
- Place the scanner on the wall and move it slowly and evenly in one direction without lifting it.
- The display shows the type of object (metal, wood, live cable) and the approximate depth.

3. Marking

- When the object is under the centre, mark its position through the marking hole.
- Scan in the perpendicular direction too to find the direction of the object.

4. Tips

- Always check a spot several times before drilling.
- Wet concrete and metal foil can disturb the measurement — use the right mode.

5. Safety and care

- The scanner cannot give a 100 % guarantee — drill carefully, especially near electrical wiring.
- Do not use the scanner in rain; protect it from falls.
- If the equipment does not work properly, stop using it and call us: +371 26537465.

6. Returning

- Return the equipment to Slokas iela 52N clean and complete — with all accessories listed in the hand-over record.

Based on the Bosch manufacturer’s instructions. Full manufacturer manual: www.bosch-professional.com.