ONERENT · QUICK USER GUIDE

# Surface cleaner Kärcher FRV 30 ME

A short guide to the surface cleaner for a pressure washer: connecting and cleaning paving or decking without splashes.



## 1. Before you start

- Check that the kit contains everything listed in the hand-over record.
- The surface cleaner works only with a suitable pressure washer (M22 × 1.5 connection).
- Check that the nozzles under the housing are clean and rotate freely.

## 2. Surface cleaner FRV 30 ME

- Attach the surface cleaner to the gun instead of the spray lance.
- Move it slowly over paving or decking in slightly overlapping strips; the built-in suction collects the dirty water.
- Do not lift the cleaner from the surface while the trigger is pressed.

## 3. After work

- Rinse the housing and underside with clean water.
- Check that no stones are stuck between the nozzles.

## 4. Tips

- Sweep away coarse dirt and sand before cleaning.
- Pre-treat very dirty joints with the spray lance.

## 5. Safety and care

- Never point the jet at people, animals, electrical devices, tyres or the machine itself.
- Wear safety glasses and non-slip shoes.
- If the equipment does not work properly, stop using it and call us: +371 26537465.

## 6. Returning

- Return the equipment to Slokas iela 52N clean and complete — with all accessories listed in the hand-over record.

Based on the Kärcher manufacturer’s instructions. Full manufacturer manual: www.kaercher.com.