ONERENT · QUICK USER GUIDE

Petrol lawn aerator Gudnord SC 40/45

A short guide to the petrol aerator/scarifier: checks before work, starting and treating the lawn.



1. Before you start

- Check that the kit contains everything listed in the hand-over record.
- Check the engine oil level and refuel (clean petrol) only with the engine off and cool, outdoors.
- Before work, mow the lawn shorter and clear it of stones, branches and other objects.

2. Starting

- Set the working depth for your lawn — start shallower.
- For a cold engine, close the choke, then pull the starter cord steadily.
- Open the choke when the engine warms up.

3. Working

- Push the aerator at an even pace in straight, slightly overlapping strips.
- When turning or crossing hard surfaces, raise the working shaft or stop the engine.
- After work, rake up the moss and old grass.

4. Tips

- The best time is spring or early autumn, when the lawn is growing and the soil is not too wet.
- After treatment, the lawn can be fertilised and overseeded.

5. Safety and care

- Never put hands or feet under the housing while the engine is running; wear closed shoes.
- Stop the engine and remove the spark plug lead before cleaning or adjusting.
- Do not run it indoors — exhaust gases are dangerous.
- If the equipment does not work properly, stop using it and call us: +371 26537465.

6. Returning

- Return the equipment to Slokas iela 52N clean and complete — with all accessories listed in the hand-over record.
- Return the aerator cleaned of soil and grass.

Based on the Gudnord manufacturer’s instructions. The full manual is included with the device.