ONERENT · QUICK USER GUIDE

Material moisture meter Testo 606-2

A short guide to the pin-type material moisture meter: choosing the material, measuring and air humidity.



1. Before you start

- Check that the kit contains everything listed in the hand-over record.
- Check the battery charge.
- Remove the electrode protection cap.

2. Material moisture

- Switch on and choose the material curve (wood or building material).
- Push both electrodes fully into the material; in wood, across the grain.
- Read the value and measure at several spots.

3. Air humidity and temperature

- Switch the meter to air humidity and temperature.
- Let the meter adapt to the room temperature for a few minutes.

4. Tips

- Do not measure on a surface wet from rain or condensation — the result will be too high.
- Do not force the electrodes into hard material (concrete) — they can break.

5. Safety and care

- The electrodes are sharp — put the cap back on after work.
- Do not measure near electrical wiring.
- If the equipment does not work properly, stop using it and call us: +371 26537465.

6. Returning

- Return the equipment to Slokas iela 52N clean and complete — with all accessories listed in the hand-over record.

Based on the manufacturer’s instructions (testo SE & Co. KGaA). Full manufacturer manual: www.testo.com.