ONERENT · QUICK USER GUIDE

Upholstery and carpet cleaner Kärcher Puzzi 10/1

A short guide to the upholstery and carpet cleaner: preparation, spray-extraction cleaning and cleaning after work.



1. Before you start

- Check that the kit contains everything listed in the hand-over record.
- Fill the clean water tank with warm water (not hotter than the manufacturer allows) and add cleaning agent as dosed on the pack.
- Connect the hose and the right tool — the hand tool for upholstery or the floor tool for carpets.

2. Cleaning

- Plug into a 230 V socket and switch on the pump and suction.
- Holding the lever, move the tool slowly over the surface — the solution is sprayed and sucked up at once.
- Then go over the same area again without spraying to remove the remaining moisture.

3. After work

- Empty the dirty water tank and rinse both tanks with clean water.
- Suck a little clean water through the tool to rinse the hose.

4. Tips

- Test the fabric on a hidden spot first.
- Use only low-foam agents intended for such machines.
- Drying can be sped up with the Master 5000 air mover.

5. Safety and care

- Do not run the machine without water and do not let the dirty water tank overflow.
- Unplug the machine before removing the tanks.
- If the equipment does not work properly, stop using it and call us: +371 26537465.

6. Returning

- Return the equipment to Slokas iela 52N clean and complete — with all accessories listed in the hand-over record.
- Return the machine with the tanks emptied and rinsed.

Based on the Kärcher manufacturer’s instructions. Full manufacturer manual: www.kaercher.com.